

ASSEMBLY INSTRUCTION

P1	6×50mm 8pcs	<p>Ax1 Bx1 Cx1 Dx1 Ex1 Fx1 Gx1 Hx1 Ix1 Jx1 Kx1 Lx1 Mx1 Nx1 Ox1 Px1 Qx1 Rx2 Sx1 Tx1 Ux1</p>
P2	3.5×60mm 12pcs+1spare	
P3	4×45mm 18pcs+1spare	
P4	3.5×25mm 8pcs+1spare	
P5	3×16mm 30pcs+1spare	
P6	2pcs	
P7	1pc	

